



# GÊISER 1" ½




Cód.: 997.08 - Rosca ½"


Cód.: 997.42 - Rosca ¾"



GÊISER 2"




Cód.: 997.09 - Rosca 3/4"



GÊISER 2" ½




Cód.: 997.10 - Rosca ¾"



GÊISER 3"



Cód.: 997.11 - Rosca 1"





# GÊISER 4"



Cód.: 997.12 - Rosca 1" ½  
Cód.: 997.41 - Rosca 2"

